

Instruction manual for 2.4 GHz Wireless USB Controller

Please read before use:

1. Make sure the controller is fully charged prior to first use to ensure battery is at maximum capacity.
2. Make sure to use a standard 5V 1A charger to avoid damage to the controller.
3. Do not charge the controller for over 2 hours.
4. The red LED will flash rapidly during normal use indicating that the controller is low on battery. Please charge the controller immediately to avoid losing connection.
5. The red LED will blink slowly when the controller is charging, it will disappear once the controller is fully charged and ready for use.
6. When the controller and the receiver cannot be connected successfully, press the DOWN+SELECT+START buttons at the same time, and the red LED of the controller flashes to reset. They can be paired successfully.



DOWN + SELECT + START

Pairing the controller:

1. Turn on the controller by pressing the START button, the red LED will blink slowly
2. Press the START button again, the red LED will flash rapidly indicating the controller is ready to pair.
3. Plug in the USB receiver to the PC, the red LED will stay lit to indicate the controller has been paired successfully.

LED Instructions:

1. Press "START" button, and LED flashes slowly: this handle is turned on.
2. After the handle is turned on normally, press "START" button again, and LED flashes quickly: this handle is searching for the signal from the paired device.
3. LED shines continuously: this handle has been connected and paired successfully.
4. During the charging process, LED flashes every 2 seconds: this handle is being charged, and LED turns off when the handle is fully charged.
5. LED flashes quickly intermittently: This handle is lacking power and needs to be charged.